




LG BP220 Power Cord Replacement

The removal of the power cord will allow its replacement.

Written By: Bart Quicho



INTRODUCTION

This guide will show you how to open up your Blu-ray player and remove the power cord if it is faulty and causing problems related to powering the device.



TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-


Step 1 — Power Cord




⚠ Ensure the device is unplugged to prevent shocks.

- Remove the three black 3/16" Phillips #2 screws from the backside of the player.
- With the backside (audio/video jacks) facing you, lift the part of the cover closer to you and pull until it is off.

Step 2



 Beware of the capacitors as they may shock you when touched.

- Detach the power supply cord from the brown logic board by pushing the locking clip on the connector, and pulling out.
- ⓘ The connector may be difficult to remove. Wiggling it while pulling out may help release it.
- Remove the power cord from the panel by carefully sliding it upwards from its seating.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 12:58:25 AM.